

056575 Triumph Trident 660 Extenda Fenda *EXTRA* Fitting Instructions

Kit Includes:

| | | |
|----|------------|--|
| 1X | C056575 | Moulding |
| 2X | CFK056575 | Brackets (pair) |
| 4X | CBOLM50005 | M5 X 12mm Black Stainless Steel Bolt |
| 8X | CWASM50002 | M5 Stainless Steel Washer |
| 4X | CNUTM50003 | M5 Stainless Steel Serrated Nut |
| 1X | CFOA0002 | Foam Strip 20mm X 1.5mm (cut to 200mm in length) |
| 4X | CRIV0003 | Push-rivets |

We advise the use of thread locking fluid on all the fixings for this product.

- Loosely attach the mudguard to the brackets using the M5 fixings supplied. Place the M5 stainless steel washers under the bolt head and under the serrated nuts.
- Cut and attach the foam provided in the area marked 'A' below.
- Following instructions marked 'B' below. Be sure to check alignment as you go!
- **Now tighten all the mounting points. Check fixings periodically.**

2 Once the brackets are fitted drill 4mm holes through the OEM mudguard and EXTRA Extenda Fenda. Use the push-rivets supplied to secure the two parts together.

B



1 Remove this brake caliper bolt on each side of the bike. Refit the bolt with the mudguard brackets in place as shown here.



Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!