

DL 650 V Strom Hugger – all years Part # 070194

Fitting Instructions

Kit Contains:

Moulded Fibreglass Hugger

1 x 'P' Clip (metal with rubber liner)	CFIT0012
1 x Flange Head socket screw – M5 x 20	CBOL0115
2 x Flange Head socket screw – M6 x 16	CBOL0251
2 x Open Rubber Grommets	CGRO0013
2 x ¼" dia' x 6mm Steel Collar	CGRO0017



First remove the left hand side passenger foot rest to allow better access (2 x socket bolts).

Using a **large** posi-drive screwdriver, remove the chain guard.

Now, moving to the right side of the bike, use a smaller posi-drive screwdriver to remove the single M5 screw that fixes the plastic guide for the brake hose/abs line to the swinging arm. *- Dis-guard this plastic guide.*

Now insert the two open rubber grommets in the pre-drilled holes on the chain guard side of the Hugger. Followed by the steel collars.

Sit the Hugger over the rear wheel and down onto the swinging arm. **Loosely** attach it on the chain guard side with the two M6 x 16 socket screws.

Now open up the 'P' clip and pass it around the brake hose and the ABS line with the open ends of the clip facing towards the Hugger – *See image above.*

Now attach loosely using the M5 x 20 socket screw. *I small individual Allen key is best for this. **Take care not to get this bolt cross threaded!***

Fully tighten the two bolts on the chain guard side.

Now fully tighten the M5 now. **Note:** There is some tolerance in this mounting to allow final adjustment of the Hugger over the centre of the tyre.

Now re-fit the left hand passenger footrest.

Check all fasteners are tightened as required.