



GSX 650F Hugger

2008 - 2013

- Fittings:
- a) 2x M6x16 Stainless steel allen bolts
 - b) 1x M6x20 Stainless steel allen bolt
 - c) 2x Black plastic washers

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked periodically for tightness.

Hugger Fitting Instructions

The fitting is easier with the bike on a paddock stand.

1. Remove the existing chain guard.
2. Open up the two retaining tabs to release the break hose from the swinging arm face.
3. Remove the break hose clip nearest to the rear of the swinging arm, (this is replaced later).
4. Feed the hugger over the tyre and into position, aligning the tab on exhaust side of the bike over the mounting hole. Then place the break hose clip over the top of the tab fit loosely using (b).
5. Attach hugger loosely on chain side using 2x (a) and 2x (c).
6. Fully tighten all fasteners checking left/right alignment over tyre as you do so.
7. Feed break hose back into clips and check alignment over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.