

SV650 03-6 Hugger

Part # 07032

Hugger Fitting Instructions

Fittings: a)	1x Strap bracket for right hand swinging arm (2 piece)	CFK07311
b)	4x M6x16 Stainless steel allen bolts	CBOL0251
c)	1x M6x12 Stainless steel allen bolt	CBOL0123
d)	4x Black plastic washers	CWAS0221
e)	1x M6 shake proof washer	CWAS0202

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

The Job is easier with the bike on a paddock stand.

First remove the chain guard and the inner plastic flap on the top of the swing arm.

On 'N' model mount the strap bracket (a) between the 2 brake cable guide brackets by loosely attaching the single underside fastener (c)&(e). ON 'S' model unbolt and snip off brake cable guide bracket.

Offer up the Hugger and attach loosely to the chain side using 2x (b) and (d)
Attach to the right side bracket using 2x (b) and 2 x (d).

NOTE. Both fingers of the bracket should be inside the Hugger.

Fully tighten all fasteners checking left/right alignment over the tyre as you do so.
Check position of hugger over tyre.
If adjustment is required loosen all fasteners slightly to allow re-alignment.

