

SV1000 HUGGER

Part # 07035/6

Fitting kit contents

- | | |
|-----------------------------|----------|
| a) 1x Hugger | |
| b) 1x Strap bracket | CFK07015 |
| c) 4x M6 x 16mm bolts | CBOL0251 |
| d) 4x Black plastic washers | CWAS0221 |
| e) 1x M6 x 12mm allen bolt | CBOL0123 |
| f) 1x M6 Shake proof washer | CWAS0202 |

Fitting instructions

1. Remove chain guard
2. Place the strap bracket around the right hand side of the swing-arm, this should be located to the rear of the brake guide bracket and secured at the bottom mounting using 1x (e) and 1x (f).
3. Feed the hugger in over the wheel and position over and to the outside of the strap bracket and the two chain guard mount points.
4. Loosely attach the hugger while in position to the strap bracket using 2x (c) and x2 (d).
NOTE. Both fingers of the bracket should be inside the hugger.
5. Loosely attach the chain guard side to the two chain guard side mounting points again using 2x (c) and x2 (d).
6. Move the strap bracket with hugger attached until the hugger sits centrally on the tyre and the brake cable guide bracket sits centrally in the slot on the hugger.
7. Fully tighten all bolts.

Note:

If for whatever reason a better position is needed from the hugger this can usually be achieved by loosening all the bolts and re-tightening while the hugger is being pulled across by hand.

