

VTR1000 Hugger

Hugger Fitting Instructions

Fittings: a) 2x M6x12 S/steel Dome head bolts	CBOL0123
b) 2x Black plastic washers	CWAS0221
c) 1x length of foam fitted	CFOA0010

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear.

The Job is easier with the bike on a paddock stand.

First remove the chain guard and the rear brake hose clips.

The rear plastic hose retaining clip requires modification in order for it to sit flat on the hugger face. See diagram below.

The Shaded area should be removed with either a metal file or sanding block to leave a flat face.

The Hugger design requires the original chain guard to be refitted over the hugger using the two M6x12 dome head bolts provided.

Fully tighten all fasteners checking left/right alignment over the tyre as you do so.

Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.

