

## Part # 07124

# Sp1 Hugger

### Hugger Fitting Instructions

Fittings: a) 1x Bracket	CFK07123
b) 4x M6x16 Stainless steel allen bolts	CBOL0251
c) 4x Black plastic washers	CWAS0221

### General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

\*\*\*\*\*

The Job is easier with the bike on a paddock stand.

First remove the chain guard and the rear brake hose clip.

Mount the bracket (a) by fitting it around the captive nut, and under the break hose.

Attach the hose clip, securing bracket onto swingarm with brake line in between bracket and clip.  
**DO NOT** pinch brake hose or bend it in any way.

Offer up the Hugger and attach loosely to the chain side using 2x (b) and 2x (c).  
Attach to the right side bracket using 2x (b) and 2x (c).  
Ensure bracket fits inside of hugger.

Fully tighten all fasteners checking left/right alignment over the tyre as you do so.  
Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.