



VARADERO XL1000V HUGGER

PART # 071240

Fitting kit:

2 x M6 x 20mm allen bolt	CBOL2165
2 x M6 x 16mm allen bolt	CBOL0251
4 x M6 plastic washer	CWAS0221

Fitting instructions:

In order to fit this hugger it is necessary to remove the rear wheel.

Remove the chain guard.

Remove the bolts from the two aluminium brake hose clips, leaving the clips in place as the hugger slides over these.

Do not tighten fasteners fully in the first instance

Position the hugger, secure on the original chain guard mounts using two m6 x 16mm bolts and washers, and over the brake hose clips (retaining the clips) using the M6 x 20mm bolts and washers.

Refit the wheel and check hugger alignment before finally tightening fasteners.

Please note: check hugger alignment and fasteners periodically.