

Part # 07126

SP-2 HUGGER **FITTING INSTRUCTIONS**

FITTING KIT:

1 x hugger.

1 x plastic anchor rivet – CNUT0110

INSTRUCTIONS:

1. Remove chainguard.
2. Remove brake pipe clip opposite side.
3. Slide hugger in over rear wheel.
4. Line hugger up with holes on swing arm
5. Place original chainguard on top and line up with holes
6. Attach rear bolt finger tight on chainguard side, push front clip fastener through chainguard and hugger into the relevant hole in the swing arm
7. Re-attach brake hose clip using original bolt
8. Align hugger centrally and tighten bolts while pressing the plastic outer of the fastener down firmly carefully tighten the metal insert until tight being careful to avoid fingers!!