

Part # 07136

HORNET600 Hugger

2005-2006

Fitting kit contains

1 x Hugger,	
1 x Bracket	CFK07136
2 x M6 x 12mm button head Allen bolts	CBOL0123
4 x M6 Black plastic washers	CWAS0221
2 x M6 x 16mm Allen bolts	CBOL0251

1. Remove the brake pipe guide bracket.
2. Loosen the 2 left hand side foot rest hanger bolts and remove the top bolt.
3. Lower the hanger to gain access to the front chain guard bolt.
4. Remove the chain guard retaining bolts and take off the chain guard.
5. Take the Pyramid hugger and feed it in from the left hand side over the wheel
6. Attach the pyramid bracket to the right side of the hugger arm using the 2x M6x12mm button head Allen bolts and 2 x M6 Black plastic washers.
7. Replace the brake pipe guide bracket using the original fixing bolt trapping the new hugger bracket in place.
8. Offer up the chain guard side to the chain guard mount brackets and loosely attach 2 m6 x 16mm countersunk bolts and washers.
9. There will be some play in the holes so if needed a better fit can be achieved by loosening the bolts, positioning the hugger by pulling the relevant side and re-tightening the bolts while being held in required position.
Reattach the footrest hanger making sure all the bolts are fully tightened

