

Fazer 600 Hugger 2002 – 2003

Hugger Fitting Instructions

Fittings: a) 2x M6x16 countersunk allen head bolts CBOL0216
 b) 2x Stainlesssteel countersunk washers CWAS0002
 c) 1x Stainless steel Teardrop Bracket CFK07226
 d) 1x M6x20 Dome head allen bolt CBOL2165
 e) 2 x M6 rubber washer CWAS0901

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

The Job is easier with the bike on a paddock stand.

1. First remove the chain guard. (3 Bolts)
2. Remove the brake hose guide. (1 bolt)
3. Feed the hugger in over the wheel.
4. Position the right hand flange of the hugger under the brake pipe.
5. Attach the hugger loosely to the chain side using the two M6x12 bolts and washers provided.
6. replace the break hose guide placing the teardrop bracket provided between the guide and the hugger flange using the M6x20 bolt provided.

Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.

NOTE!:

ALL PYRAMID PRODUCTS ARE DESIGNED USING THE FACTORY STANDARD BIKES WITH STANDARD TYRES ETC... SO ANY LARGER SIZE TYRES MAY AFFECT THE FIT.