

Part # 07371

ZX10R 06 Hugger

Fitting Instructions (for the later models without a swing arm cross brace)

Fitting kit contents

1 x hugger

1 x m6 x 20mm Allen bolt – CBOL2165

1 x shakeproof washer – CWAS0202

As with all huggers this model is designed to fit close to the tyre section, and as such should not be used where an oversize tyre is fitted.

Fitting Instructions.

1. Remove the brake pipe guide clip from the swing arm, leaving it attached to the brake line.
2. Remove the chain guard retaining bolts and take off the chain guard.
3. Take the Pyramid hugger and feed it in from the left hand side over the wheel.
4. Offer up the chain guard side to the chain guard mount brackets and loosely attach the original bolts.
5. Feed the hose clip through the hole in the hugger and position as originally mounted.
6. Using the supplied 20mm Allen bolt and shakeproof washer re-attach the hose clip, taking care to align the top in the pre-drilled hole/recess.
7. Tighten the chain guard side bolts then the hose clip bolt.
8. There will be some play in the holes so if needed a better fit can be achieved by loosening the bolts, positioning the hugger by pulling the relevant side and re-tightening the bolts while being held in required position.