

## **VERSYS 650 2006 > Hugger**

## **Contents:**

3 x M6 x 20mm button head Allen bolt 3 x 13mm grommet 2 x 6mm steel collar 1 x 8mm steel collar

## **Fitting instructions:**

- Remove original chain guard, brake hose clip bolt (on bikes pre 2016).
  2017 models the clip has moved and the hole is now covered with a plastic blank.
  This is easily removed by hand, take care not to scratch swing arm if using a tool.
- 2. Fit the supplied grommets and steel collars to the 3 holes in the Hugger. The larger 8mm steel collar should be installed in the grommet next to the shock absorber mounting.
- 3. Slide hugger over the tyre from the rear and attach the tab on right hand side onto the top of the swing arm using 20mm Allen bolt (not fully tightened)
- 4. Attach chain guard side of hugger using 2 x 20mm allen bolts (not fully tightened)
- 5. Attach original brake hose clip bolt with brake hose clip on outside of hugger (pre 2016).
- 6. Check alignment of hugger and tighten all fixings fully.

## Note:

Please check all fasteners and alignment of the hugger periodically.

This hugger is not designed for use with an oversize tyre.

Pre load should be at maximum if carrying heavy luggage or passengers over 10 stone (63.5Kg / 140lbs).