

## **KTM Duke 125/200/390 Rear Hugger**

### **Part # 079301**

#### **Kit Includes:-**

2x M6 Grommets with sleeves	CGRO0013/CGRO0017
2x M6 x 20mm flange headed bolt	CBOL2165
2x m6 plastic washer	CWAS0221
1x M5 x 20mm flange headed bolt	CBOL00115
1x M6 Nyloc nut	CNUT0200



1. Using a 14mm and 19mm ring spanner or socket remove the bolt on the bottom right of the gear pedal assembly and just loosen the other two.
2. Now remove the standard KTM chainguard and Hugger.
3. Insert the grommets and sleeves into the two 13mm holes on the right hand side of the hugger. Then place the Hugger on the bike.

*Use the M5 x 20mm flange head bolt in the **rear** grommet.  
Use a M6 x 20mm flange head bolt in the **front** grommet.*

4. Replace the standard KTM bolt back in the front chainguard mounting point with one of the plastic washers provided.
5. Place the remaining M6 x 20mm flange headed bolt and plastic washer into the rear chainguard mounting using the M6 Nylock nut.
6. Check and tighten where necessary all five mounting points for the new Hugger.
7. Re-tighten the three bolts on the footrest hanger.