

# PYRAMID



## 20681 Suzuki SV650 N Belly Pan Fitting Instructions

### Kit Includes:

3X	Mounting Brackets	CFK20681
6X	M6 X 16mm Bolts	CBOL0251
4X	M6 Nyloc Nuts	CNUT0200
4X	M6 Flat Steel Washers	CWAS0201
4X	Rubber Grommets	CGRO0013
4X	Steel Collars	CGRO0017

- Three brackets are supplied. Mount as shown below.
- 2X **M6 X 16mm Bolts** are provided to mount the forward bracket in the pre-drilled holes in the engine casing. The other mountings use existing engine bolts.
- Now insert the **Rubber Grommets** and **Steel Collars** in the four pre-drilled belly pan holes.
- Now mount the belly pan with the 4X **M6 X 16mm Bolts**, **M6 Nyloc Nuts** & **M6 Flat Steel Washers** provided.



### Got questions?

sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!