



250000 Ducati Scrambler Nose Fairing

Kit Includes:

2X M6 x 12mm Flange headed bolts	CBOL0123
1X M5 x 16mm Black bolt	CBOL0163
1X M5 Anchor Nut	CNUT0152
1X M5 Black Plastic Washer	CWAS0100
1X M6 Black Plastic Washer	CWAS0221
1X M6 x 4mm White Plastic Spacer	CSPA0009
1X Black Bracket	CFK250000

- Remove indicator fixings on both sides of the headlight (**Fig 1**).
- Remove the highlighted bolt (**Fig 2**) holding the small bracket situated under the bottom yoke.
- Fit the bracket using both the M6 x 12mm Flange Headed Bolts. The M6 x 4mm White Plastic Spacer (fits at point **A** in **Fig 3**) & M6 Black Plastic Washer (fits at point **B** in **Fig 3**) fit between the bracket and the bolt holes.
- Once aligned, fully tighten and place the M5 Anchor Nut in the last hole on the bracket.
- Now attach the Nose Fairing to the indicator mounting points using the original indicator fixings.
- Lastly, fit the M5 x 16mm Black Bolt & M5 Black Plastic Washer through the hole at the bottom of the Nose Fairing and attach to the M5 Anchor Nut in the bracket.

