


816000 - Triumph Explorer 1200 Shock Shield Fitting Instructions



1. Fully clean the mounting surface using hot soapy water and dry with a towel.
2. Wipe and fully clean the mounting surface using the alcohol wipe provided.
3. Peel off the protective layer from the High Bond tape on the Shock Shield.
4. Offer up the Shock Shield to the motorcycle (as shown in photo) but do NOT allow the tape to come into contact with the mounting surface until a decent fit is achieved.
5. Prop a length of dowel or suitably high strength cardboard tube between the wheel and the recess in the shock shield to hold the Shock Shield firmly in place.
6. LEAVE OVER NIGHT BEFORE RIDING to ensure a proper bond.

Find more for your motorcycle by visiting www.pyramid-plastics.co.uk


816000 - Triumph Explorer 1200 Shock Shield Fitting Instructions



1. Fully clean the mounting surface using hot soapy water and dry with a towel.
2. Wipe and fully clean the mounting surface using the alcohol wipe provided.
3. Peel off the protective layer from the High Bond tape on the Shock Shield.
4. Offer up the Shock Shield to the motorcycle (as shown in photo) but do NOT allow the tape to come into contact with the mounting surface until a decent fit is achieved.
5. Prop a length of dowel or suitably high strength cardboard tube between the wheel and the recess in the shock shield to hold the Shock Shield firmly in place.
6. LEAVE OVER NIGHT BEFORE RIDING to ensure a proper bond.

Find more for your motorcycle by visiting www.pyramid-plastics.co.uk

816000 - Triumph Explorer 1200 Shock Shield Fitting Instructions



1. Fully clean the mounting surface using hot soapy water and dry with a towel.
2. Wipe and fully clean the mounting surface using the alcohol wipe provided.
3. Peel off the protective layer from the High Bond tape on the Shock Shield.
4. Offer up the Shock Shield to the motorcycle (as shown in photo) but do NOT allow the tape to come into contact with the mounting surface until a decent fit is achieved.
5. Prop a length of dowel or suitably high strength cardboard tube between the wheel and the recess in the shock shield to hold the Shock Shield firmly in place.
6. LEAVE OVER NIGHT BEFORE RIDING to ensure a proper bond.

Find more for your motorcycle by visiting www.pyramid-plastics.co.uk

816000 - Triumph Explorer 1200 Shock Shield Fitting Instructions



1. Fully clean the mounting surface using hot soapy water and dry with a towel.
2. Wipe and fully clean the mounting surface using the alcohol wipe provided.
3. Peel off the protective layer from the High Bond tape on the Shock Shield.
4. Offer up the Shock Shield to the motorcycle (as shown in photo) but do NOT allow the tape to come into contact with the mounting surface until a decent fit is achieved.
5. Prop a length of dowel or suitably high strength cardboard tube between the wheel and the recess in the shock shield to hold the Shock Shield firmly in place.
6. LEAVE OVER NIGHT BEFORE RIDING to ensure a proper bond.

Find more for your motorcycle by visiting www.pyramid-plastics.co.uk