



## **13800 Kawasaki ZZR1400 Seat Cowl**

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



## **13800 Kawasaki ZZR1400 Seat Cowl**

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



## **13800 Kawasaki ZZR1400 Seat Cowl**

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



## **13800 Kawasaki ZZR1400 Seat Cowl**

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



## **13800 Kawasaki ZZR1400 Seat Cowl**

- Remove seat & seat strap.
- Slide Seat Cowl on from the rear of the seat.
- Fit the Seat Cowl to the strap mounting points using the original fittings.

sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk